

A PerTronix Performance Brand ~ www.pertronixbrands.com ~ 909 599-5955

## Installation Instructions & Warranty Information 1931S ~ 2002-08 Dodge Ram 3.7 Cat4Ward® Headers





# PERTRONIX PERFORMANCE BRANDS EMISSIONS CODES

This product has been granted a California Air Resources Board (CARB) Executive Order (EO Number) Exemption. It is 50 State Legal when installed on the Specified vehicle per the Manufacturer's Current Application Guide, the CARB EO, and Installation Instructions.

REV 3/2022

### **MARNING:**

This product can expose you to chemicals including
Lead, Nickel, Cadmium and Chromium which are known to the
State of California to cause cancer and birth defects or other
reproductive harm. For more information go to
www.P65Warnings.ca.gov

#### PLEASE READ BEFORE PROCEEDING

PerTronix<sup>®</sup> thanks you for choosing a JBA Performance Exhaust Product. To realize the potential of JBA's engineering and excellent fit, Please Read and Understand these instructions completely prior to starting the installation.

Check that you received all the parts listed on the parts list, if you have any concerns, please contact PerTronix before continuing. Headers will have the part number stamped in the flange.

Work Smart – Work Safe! Most Header and Exhaust Installation are best performed on a lift. If a lift is not available, raise the vehicle and support on quality Jack Stands on level ground. Do not rely on a jack!

We use sealing beads on all our headers. The raised bead creates a better seal virtually eliminating leaks if installed properly. It is important to install all header bolts lightly snug and then tighten to factory torque specs starting in the center and working outward.

Before starting, allow the vehicle to cool, disconnect the battery, and spray a penetrating oil on all hardware and fittings that will need to be removed. Once you remove your manifold, clean the sealing surface on the head of any old gasket debris or carbon build up.

Warning! The header gaskets on this vehicle are made of thin stainless steel.


They are EXTREMELY sharp! Wear gloves!

- 1. Disconnect the battery cables.
- Unbolt exhaust pipes from exhaust manifolds.
- 3. Unbolt heat shields from manifolds and remove the heat shields.
- 4. Unplug the 02 sensor connectors,
- 5. Unbolt exhaust manifolds and remove the manifolds.
- 6. Clean the sealing surface on the cylinder heads.
- 7. Install headers using the provided gaskets and hardware.
- 8. Apply a small bead of sensor safe high temp RTV to the header domes/
- 9. Connect the exhaust to the headers using supplied hardware.
- 10. Reconnect battery cables.
- 11. Start engine, check for leaks. Let the engine cool down then re-tighten the header bolts. Recheck the bolts periodically as header bolts tend loosen with heat cycles.

#### Parts List

- (1) Driver's Side Header Assembly
- (2) Head Flange Gaskets
- (2) 3/8" x 2"
- (2) 3/8" Flat Washer
- (1) CARB EO Sticker

- (1) Passenger's Side Header Assembly
- (2) 3/8" x 2-1/4" Bolt
- (2) 3/8" Nut
- (2) 3/8" Serrated Flange Nut



#### WARNING

This label is required to aid in passing the California smog check program. This label must be installed in an underhood location that is readily visible.

### JBA LIMITED WARRANTY

All JBA Headers and Exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.