



Installation Instructions

817490

2009-19* RAM 1500

4.7L, 5.7L HEMI ENGINE

2/4 Wheel Drive & All Wheelbases

With Factory Single Tailpipes

*2019 Classic Body Only

OVERVIEW:

1. Take a moment to read and understand these instructions before installing your Flowmaster performance system.

NOTE: Please inventory all parts now before continuing and if necessary, report any missing items to our tech line. This will avoid potentially stranding your vehicle until any missing replacement parts arrive.

ITM #	PART #	DESCRIPTION	QTY.
1	TB467S	Adapter Pipe	1
2	8530572-Z	AMT Muffler	1
3	16629S	Right Tailpipe	1
4	16392S	Left Front Tailpipe	1
5	16393S	Left Rear Tailpipe	1
6	16662S	Rear Exit Pipes	2
7	16317S	Side Exit Pipes	2
8	ST396	Stainless Tips	2
N/A	PK552	Hardware Package includes:	1
9	MC250BS	2½" Band Clamps	5
10	MC300BS	3" Band Clamps	2
11	HA168	Rubber Hanger	1

REMOVE STOCK EXHAUST SYSTEM:

2. Raise vehicle up on a hoist or rack to working height. If you don't have access to a hoist or rack, support vehicle with jack stands.

WARNING:

Avoid serious burns! Allow your vehicle time to cool completely before touching any factory engine components.

To ease preparation and installation of your new kit:

- Apply penetrating lubricant to mounts, bolts and clamps before you remove them.
- Use stands as necessary to support parts as you detach them from your vehicle and again as you install new parts.

